


Nautilus Hyosung CDU Binding Windows CE 6.0 & 7.0 ATMs*

- Log into ATM
- Select “Customer Setup”
- Select “Optional Function2” Select “Device Option”
- Set “CDU BINDING OPTION” to “ENABLE”
- Verify CDU Binding shows ENABLE



- Press Cancel 4 Times to Exit the Operational Menu
- Done

Please Note: CDU Binding is not available on WinCE 5.0 ATMS – 1800CE and 5000CE Models.