



HYOSUNG
CDS Processor
Enhanced STD 1 – Dial Up

Enter into Operator Functions using master password

Press **SYSTEM SETUP**

1. Select CHANGE PASSWORD (Change all three, use different passwords for each)
 - a. Press OPERATOR PASSWORD (Lowest level, for accessing reports)
 - b. Press SERVICE PASSWORD (All but most crucial menus can be accessed)
 - c. Press MASTER PASSWORD (Access to all programming menus)
2. Cancel
3. Device Setup | NH EMV | Yes to confirm (as long as it is an EMV reader)
4. CANCEL 3 times

Press **CUSTOMER SET UP**

1. Select SURCHARGE MODE
 - a. Make sure SURCHARGE is set to **ENABLE**
 - i. If not, press EN/DISABLE until screen reads **ENABLE**
 - b. Press AMOUNT
 - i. Set amount by using the key pad
 - ii. Press Enter
 - c. Press SURCHARGE OWNER
 - i. Press Alpha for letters
 - ii. Enter Corporate name or Business name using key pad
 - iii. Press OK
 - iv. Press Cancel 2 times
2. Press SELECT PROCESSOR
 - a. Select COMMUNICATION
 - i. Make sure it set to **DIAL-UP**
 - ii. Press Cancel
 - b. Select MESSAGE FORMAT
 - i. Press STANDARD 1
 - ii. Press Cancel

- c. Select EOT/ENQ OPTION
 - i. Press NO EOT REQUIRED (ENQ is displayed as REQUIRED)
 - ii. Press Cancel twice
- d. Select STANDARD 1 OPTION
 - i. Terminal Status **ENABLED**
 - ii. Reversal at Host error **ENABLED**
 - iii. Reason for reversal **DISABLED**
- e. Extended Functions ****ENSURE DCC Features are DISABLED for DIAL-UP****, (These features are available on CT ATM+ software)

- 1. Dynamic Flow **DISABLE**
- 2. 1st Call **DISABLE**
- 3. Pin Change **DISABLE**
- 4. Currency Conversion **DISABLED**
- 5. Cancel twice

3. Select OPTIONAL FUNCTION1

- a. Press BALANCE AT START
 - i. **ENABLE** BALANCE AT START
 - ii. **ENABLE** CONTINUE
 - iii. Cancel
 - iv. EMV|EMV Set to Enable
 - v. AID List: Disable 1, 13 through 16 and then 19 and 20 leaving ONLY 13 AID's enabled
 - vi. Use Common AID: ENABLE
- b. Select Accounts
 - i. **Enable** Checking, Savings and Credit Cardtronics
 - ii. Cancel
- c. RECEIPT OPTION
 - i. Select Receipt **ENABLE**
 - ii. Receipt ON SCREEN **ENABLE**
 - iii. Cancel

****ENSURE DCC Features are DISABLED for DIAL-UP****

d. Select Other Transaction (These features are available on CT ATM+ software)

i. TDL Option – **DISABLE ALL**

1. Dual Balance **DISABLE**

2. Dynamic Surcharge **DISABLE**

3. Currency Conversion **DISABLE**

ii. Cancel 3 times

4. Select CHANGE MESSAGE

a. Select WELCOME MESSAGE (Welcome message is displayed when ATM is idle)

i. Select Alpha for letters

ii. Use key pad to enter message

iii. Press OK

b. Select RECEIPT ADDRESS AND PHONE NUMBER (This will display as the name of business and address)

i. Select Alpha for letters

ii. Use key pad to enter message

iii. Press OK

c. Press Cancel 3 times

Press **HOST SETUP**

1. Select TERMINAL ID

a. Use key pad and enter the terminal number (P number)

b. Press Alpha for letters (continue to press to go back to numbers)

2. Select ROUTING ID

a. Clear Line

b. Press Alpha

c. Change routing ID to **CDHY**

d. Select OK and then cancel

3. Select TELEPHONE NUMBER
 - a. Press HOST PHONE #1 = **1-866-923-3608**
 - b. Press Enter
 - c. Press HOST PHONE #2 = **1-866-501-7536**
 - d. Press Enter
 - e. Press Cancel
4. Select REMOTE MONITOR
 - a. Press En/disable once
 - i. RMS should be **DISABLED**
 - b. Press Cancel 2 times

5. Select KEY MANAGEMENT
 - a. Press ENTER MASTER KEYS
 - b. Press YES
 - i. Enter password 1, default is **000000**
 - ii. Enter password 2, default is **000000**
 - c. Press CHANGE PASSWORD
 - i. Press PASSWORD 1
 1. Enter new password 1 (must be six digits, do not use 000000)
 2. Verify PASSWORD 1
 - ii. Press PASSWORD 2
 1. Enter new password 2 (must be six digits, do not use 000000)
 2. Verify PASSWORD 2
 - iii. Press Cancel
 - d. Press KEY MODE until **TDES** key mode is displayed
 - e. Press EDIT KEY
 - i. Select MASTER KEY PART A
 1. For KEY INDEX press 1
 2. Press Enter
 3. Enter Master Key A Left twice
 4. Enter Master Key A Right twice
 5. Press Enter

- ii. Select MASTER KEY PART B
 1. For KEY INDEX press 1
 2. Press Enter
 3. Enter Master Key B Left twice
 4. Enter Master Key B Right twice
 5. Press Enter
 - f. Press Cancel 3 times

TRANSACTION SETUP

1. Check Dispense Limit is correct (\$200 is standard)
2. Low Currency Check **DISABLE**
3. Set Fast Cash amounts
4. Check Denomination is correct
5. Make sure ATM is connected to a phone line
6. Press Cancel exit OPERATOR FUNCTIONS